

Airbus A330 TOOLS

JOB AIR Technic a.s.

PN	DESCRIPTION
98F27508237001	SUPPORT STRUT-FLAP
98F27508225000	PIN-INSTALATION, FLAP FAIRING
9522A	ENGINE RUN SIMULATION TOOL
98F29208457000	PIN-SAFETY,RAT
98F32001003000	SAFETY PIN FREE-FALL NLG
98F32104013000	SAFETY COLLAR-DOOR MLG
98F32303001000	SOCKET SPANNER SET
98F34103003000	FLUSHING TOOL – PITOT PROBE
98F57508736000	WRENCH
98F71201006034	BOOTSTRAP
98A28101000000	ADAPTING PIPE - WATER DRAINING FROM FUEL
98A28104030000	ADAPTOR BANGO KIT
98A49009001001	DEVICE - CLEANING, APU
98A57304002000	EXTRACTION, MANHOLE BOLT
98F27201002000	SAFETY PIN-RUDDER
98F27508378000	BOLT-SECURING SPRING
98F27808212000	DRIVE TOOL-34 TEETH
98F29003503000	SPECIAL WRENCH
98F57004007000	GUIDE-ACTUATOR LINK
ES750-51	ASSY GAUGE PDU ROLLER WEAR
ES750-53	GAUGE-ENDPIECE
ES750-55	GAUGE-PDU ROLLER WEAR
ES750-57	GAUGE-PDU ROLLER WEAR
PWA88000	LIFTING SLING-THRUST REVERSER
PWA88010	SUPPORT SAFETY -FAN COWL
PWA88013	UNLOCK-THRUST REVERSER
324477	PROTECTIVE CAP-FIRE EXTINGUISHER CARTTRIDGE
HU19036-1	EXTRACTOR-BOROSKOPE PLUG
HU89025-1	SLING INTAKE
HU87133	THRUST REVERSER SLING
98F27508209000	PIN SET-NEUTRAL SETTING
PWA88011	SUPPORT, SAFETY . PDO ACTUATOR T R
PWA88012	PIN, LOCK-DIRECTIONAL CONTROL VALVE
PWA88052	SLING - ATF FAN COWL